


# Y5

Synchro Tilt  
3 Paddle

# Control Guide

Enjoy the ride with this high function full 2:1 synchro control featuring an independent back angle adjustment. 4 position back lock, side tension control and built in seat slider depth adjustment.



**Seat Slider Paddle:**  
Press and hold down the seat slider paddle and move the seat to the desired location and release the paddle to lock the seat in place.



**Back Multi-Lock W/ Safety Release:**  
Lift the lever up to release the back. Angle the back into desired lock position then push the lever down to lock the back into place.

Right when seated

Left when seated



**Tilt Tension Control Knob:**  
Pull the knob outward for easy access and turn knob clockwise to tighten the tilt tension and counter clockwise to loosen tilt tension.



**Seat Height Lever:**  
Lift the lever to raise the seat, Release the lever to lock at the desired height. Lift and hold lever while applying weight on seat to lower seat height.



**Infinite Back Angle Adjustment:**  
Lift the lever up to release the back. Angle the back into desired position then push the lever down to lock the back into place.